

FAT ISLAND STAND UP



Tools Required (2) 7/16" Wrenches (1) 1/2" Wrench

8-Bike Island Fat Stand Up: 88" Rail Length Place Cradles 3.5" from ends Space 4.75" between Cradles







Rail



Before rack Assembly, Locate hardware and Unpack and identify all parts

ASSEMBLY INSTRUCTIONS

STEP ONE: Locate the Left End Post and one T-Base. Insert the End Post into the top of the T-Base. Adjust to the desired height by inserting 2 5/16" Knobs in the weld tabs on the T-Base.

STEP THREE: Assemble the Cradle Trays. Slide the ends of a Catch into the open tubes on the Tray and loosely securing with a 1/4" Thumbscrew.




STEP FOUR: Attach the finished Cradle to the Slide with (2) 1/4" x 3/4" Bolts and 1/4" Washers. Determine the angle you would like the Cradle at and tighten using 1/4" Washers and 1/4" Stopnuts.




STEP TWO: Slide the ends of the Rail over the ears on the End Posts. Place 5/16" x 1/2" Bolts and 5/16" Washers into the holes in the Rail and tighten.




Next slide the ends of another Catch into the other end of the tray and loosely hold in place with a 1/4" Thumbscrew.





ASSEMBLY INSTRUCTIONS

STEP SIX: Insert the provided plugs into the exposed tubes for a finished look.



LOADING BIKES: Make sure the front wheel is centered over the Tray. Adjust the Catches to be snug against the tire, as shown.

CONGRATULATIONS! Your Stand Up is Complete!

ADD-ON INSTRUCTIONS



For Add-On Sections, repeat Step One and insert the Connector Post into a T-Base, as shown in Diagram 8.

Then, repeat Step Two and slide two rails onto the ears, as shown in Diagram 9. This will create one long, continuous rack. Use the remaining End Post for the end of the rack.

